

Removal and Installation of Bedplate—Cleaning of Carburetor

Removal of Bedplate

1 Remove carburetor cover (113). Force closing cap (75) off (Fig. 07-3/1).




Fig. 07-3/1

75 Closing cap 113 Carburetor cover

Pull off locking ring (123) and disconnect starter connecting rod (74) (Fig. 07-3/2).




Fig. 07-3/2

74 Starter connecting rod 123 Locking ring
122 Articulated member 124 Hexagon socket screw

Loosen slotted screw (124a) on starter connecting rod (74) of earlier version of carburetor cover (Fig. 07-3/3).




Fig. 07-3/3

1st Version of Carburetor Cover

74 Starter connecting rod 124a Slotted screw
122 Articulated member

Then unscrew the 9 cheesehead screws (120) from carburetor cover (Fig. 07-3/4).

Caution! The center fastening screw is counter-sunk in the tapped hole for the air filter attachment.

Force carburetor cover with screw driver at pertinent point and remove (Fig. 07-3/5 and 6).

2 Unscrew the three cheesehead screws (107) from bedplate (77) and remove bedplate (Fig. 07-3/7).

3 Actuate piston of accelerator pump and check pump intake valve (95) for float housing for leaks (Fig. 07-3/10). Remove pump piston (102) from bedplate (Fig. 07-3/8).




Fig. 07-3/4
120 Cheesehead screws




Fig. 07-3/7
76 Seal
77 Bedplate
107 Cheesehead screws




Fig. 07-3/5




Fig. 07-3/8
102 Pump piston
105 Inner pump lever




Fig. 07-3/6
109 Seal
113 Carburetor cover
120 Cheesehead screws

4 Unscrew air correction jets of Stage I (89) and of Stage II (92). Turn bedplate around and shake

idling speed fuel jet (93), as well as the mixing tubes of Stage I (88) and Stage II (91) into the open hand (Fig. 07-3/9).

Note: If the mixing tubes or the idling speed fuel jets are too tight in bedplate, pull out with a pointed piece of wood. Never use metal for such a purpose.

5 Unscrew main jets of Stage I (87) and of Stage II (90), transition jet (94) from Stage I to II, pump intake valve (95) and pump pressure valve (97) (Fig. 07-3/10).

6 Unscrew fastening screw (85) of float holder (84) and remove holder with float (82). Watch out for float shaft (Fig. 07-3/11).




Fig. 07-3/9

- | | |
|---|--------------------------|
| 88 Mixing tube Stage I | 92 Air correction nozzle |
| 89 Air correction jet Stage I (USA version) | 93 Idling speed fuel jet |
| 91 Mixing tube Stage II | |




Fig. 07-3/11

- | | |
|-----------------|---------------------|
| 82 Float | 85 Cheesehead screw |
| 84 Float holder | |




Fig. 07-3/10

- | | |
|----------------------|------------------------|
| 87 Main jet Stage I | 95 Pump intake valve |
| 90 Main jet Stage II | 97 Pump pressure valve |
| 94 Transition jet | |




Fig. 07-3/12

- | | |
|-----------------------|-----------------|
| 80 Float needle valve | 81 Sealing ring |
|-----------------------|-----------------|

7 Unscrew float needle valve (80). Watch out for sealing ring (81) (Fig. 07-3/12).

8 Remove float housing venting valve. Check seat of venting valve in bedplate for damage.

Installation

9 Clean all jets, valves, the bedplate and the holes in the bedplate with fuel and blow-out with compressed air.

Note: Never use a needle or wire for cleaning the jets, since this will damage or widen the calibrated holes.

10 Check suction and pressure valves by shaking whether the balls in the valves are loose.

11 Install jets, mixing tubes, valves and floats.

Caution! Do not confuse jets and mixing tubes (for carburetor line-up refer to Job No. 07-0).

12 Check float level. Measure distance between float (82) and top edge of bedplate (77) without seal (Fig. 07-3/13).




Fig. 07-3/13

77 Bedplate

82 Float

The distance should be 21–23 mm. If the distance must be corrected, place pertinent sealing ring under float needle valve.

Note: Copper sealing rings are available 0.5, 1.0, 1.5, and 2.0 mm thick.

13 Check leather sleeve of pump piston for cracks or other damage. When the sleeve is damaged, the entire pump piston must be replaced. Make sleeve elastic by kneading and invert once or twice to provide again sufficient initial tension (Fig. 07-3/14). Insert pump piston into bedplate.

14 Clean float housing, blow all holes with compressed air.

15 Check vacuum system for actuating throttle valve of Stage II. For this purpose, push vacuum diaphragm on actuating rod upwards and keep




Fig. 07-3/14

Pump piston

control holes in venturis (arrows in Fig. 07-3/15) closed, release diaphragm rod. When the system is leakproof, the diaphragm should not relax.

16 Place new seal (76) on float housing and make sure that the holes and ducts are not covered by the seal (arrows in Fig. 07-3/15).




Fig. 07-3/15

76 Seal

17 Fill clean fuel into float housing.

18 Mount bedplate.

19 Check accelerator pump.

a) Checking of injected fuel quantity:

Actuate pump lever several times. If the pump piston and the pump valves have been tested and are in order, a steady fuel jet should be ejected from injection pipe. If not, replace injection pipe. For this purpose, move injection pipe (2) back and forth with pliers and pull out of bedplate (Fig. 07-3/16).

Insert new injection pipe into bedplate by applying light blows with a dull screw driver against the brass sleeve (3) (Fig. 07-3/17).

Measure amount of fuel injected. For this purpose, unscrew pressure screw (100) for preatomizer (99) and remove preatomizer (Fig. 07-3/18).

Change: Paragraph c corrected

Insert measuring vessel (1) and operate actuating lever slowly, 2–3 s/stroke (Fig. 07–3/19).

Measure amount of injected fuel several times.

b) Adjustment of injected fuel quantity:

If the amount of the injected fuel must be corrected, bend inner pump lever (105) on pertinent bending point as required (Fig. 07–3/20 arrow).

c) Checking direction of jet:

The jet should hit the wall of the venturi 10–15 mm below the upper edge of the float housing (Fig. 07–3/21).




Fig. 07–3/18

99 Preatomizer
100 Pressure screw

101 Sealing ring




Fig. 07–3/16

2 Injection pipe




Fig. 07–3/19

1 Measuring vessel
111 589 17 21 00

2 Injection pipe




Fig. 07–3/17

2 Injection pipe

3 Brass sleeve




Fig. 07–3/20

105 Pump lever





Fig. 07-3/21

Note: For vehicles with manual transmission the fuel jet may spray directly into the throttle valve gap for immediate (harder) acceleration (Fig. 07-3/21).

20 Place new carburetor cover seal on jet body and also make sure that the seal does not cover any bores of the ducts. Mount carburetor cover.

Section A-B



1 Throttle valve section manual transmission	44 Stop screw	90 Main jet (Stage II)
1a Throttle valve section automatic transmission	45 Hex. nut	91 Mixing tube (Stage II)
2 Set screw	46 Starter cover	92 Air correction jet (Stage II)
3 Set screw	47 Holding ring	93 Idling speed jet complete (Stage I)
4 Grub screw	48 Hex. screw	94 Transition jet (Stage II)
6 Articulated lever	49 Hex. screw	95 Pump suction valve
7 Restoring spring	50 Screw bolt	96 Sealing ring
8 Lock washer	51 Link plate	97 Pump pressure valve
9 Roller	52 Insulating flange	98 Sealing ring
10 Lock washer	53 Snap ring	99 Preatomizer
11 Washer	54 Cheesehead screw	100 Pressure screw
12 Lock washer	55 Float housing	101 Sealing ring
13 Idling speed mixture regulating screw	56 Cheesehead screw	102 Pump piston
14 Compression spring	57 Snap ring	103 Annular spring
15 Adjusting screw	58 Vacuum box	104 Pump lever
16 Spring washer	59 Cable holder	105 Pump lever
17 Hex. nut	60 Seal	106 Countersunk oval head screw
18 Washer	61 Snap ring	107 Cheesehead screw
19 Throttle lever compl.	62 Cheesehead screw	108 Snap ring
20 Lock washer	63 Snap ring	109 Seal
21 Spacer bushing	64 Bearing pin	110 Fuel return valve
22 Starter body	65 Actuating lever	111 Hose coupling
23 Restoring spring	66 Cheesehead screw	112 Sealing ring
24 Diaphragm	67 Hex. nut	113 Carburetor cover
25 Compression spring	68 Clamping ring	114 Seal
26 Valve cover	69 Actuating lever	115 Cover
27 Grub screw	70 Actuating lever	116 Snap ring
28 Sealing ring	71 Connecting rod	117 Cheesehead screw
29 Hex. nut	72 Pull spring	118 Snap ring
30 Countersunk oval head screw	73 Pull spring	119 Cheesehead screw
31 Driving lever	74 Connecting rod	120 Cheesehead screw
32 Transmission lever	75 Closing cap	121 Cheesehead screw
33 Snap ring	76 Seal	122 Articulated member
34 Hex. nut	77 Bedplate	123 Lock washer
35 Seal	78 Venting valve	124 Stud
36 Seal	79 Bushing	125 Bearing pin
37 Toothed washer	80 Float needle valve	126 Snap ring
38 Countersunk screw	81 Sealing ring	127 Lock washer
39 Snap ring	82 Float	128 Screw connection
40 Cheesehead screw	83 Float shaft	129 Sealing ring
41 Lock washer	84 Holder	130 Vacuum regulator
42 Stop lever	85 Cheesehead screw	131 Rubber hose
43 Compression spring	86 Snap ring	132 Cheesehead screw
	87 Main jet (Stage I)	133 Snap ring
	88 Mixing tube (Stage I)	
	89 Air correction jet (Stage I)	

